

### WEATHERBEATER™ FLOOR LINERS

#### CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater<sup>TM</sup> Floor Liner from Husky Liners. Your new front floor liners are custom molded to fit your Kia Telluride. The liners are made to take the place of your factory floor mats. <u>For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners</u>. However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liners slick.

# INSTALLATION INSTRUCTIONS FOR YOUR KIA TELLURIDE FRONT FLOOR LINERS



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR FRONT LINERS, FIRST MOVE BOTH FRONT SEATS TO THEIR MOST REARWARD POSITION. THEN, INSTALL THE LINERS, ORIENTING THEM AS SHOWN ABOVE. ONCE YOU HAVE INSTALLED YOUR LINERS, REPOSITION THE SEATS AS DESIRED. TAKE CARE THAT LINERS ARE SNAPPED OVER THE FACTORY FLOOR MAT RETAINING POSTS.






### WEATHERBEATER™ FLOOR LINERS

#### CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater<sup>TM</sup> Floor Liner from Husky Liners. Your new second seat liner is custom molded to fit your Kia Telluride. The liner is made to take the place of your factory floor mats. <u>For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners</u>. However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liner slick.

# INSTALLATION INSTRUCTIONS FOR YOUR KIA TELLURIDE SECOND SEAT FLOOR LINER



TO EASE INSTALLATION OF YOUR SECOND SEAT LINER, FIRST MOVE BOTH FRONT SEATS TO THEIR MOST FORWARD POSITION. NEXT, INSTALL THE LINER, ORIENTING IT AS SHOWN ABOVE. ONCE YOU HAVE INSTALLED YOUR LINER, REPOSITION THE FRONT SEATS AS DESIRED.