



## **Proudly Made In USA**

### **Installation Instructions:**

JK Standard Winch Guard  
Part Number: **400.100.170**

### **Vehicle Fitment:**

Fits onto JK Series Front  
Bumpers

IMPORTANT: BEFORE INSTALLING, PLEASE READ THIS INSTALLATION PACKAGE COMPLETELY

### Parts List

Qty:

- 1 Tube Winch Guard
- 4 Stainless 3/8" Allen Bolts
- 4 Stainless Flat Washers
- 6 Black Plastic Wire Guides

### Tools Needed



7/32" Allen Wrench

Congratulations on your purchase of the Hyline Offroad Winch Guard Tube. All of our products are completely manufactured in our facility located in Perkasio, PA. They are designed and engineered by Offroad enthusiasts just like you to be rock solid at an affordable price. Hyline Offroad would like to thank you for your recent purchase and look forward to serving you in the future.

*Hyline Offroad Staff*

## PLEASE READ INSTRUCTIONS BEFORE BEGINNING INSTALLATION

### \*\*\*BEFORE INSTALLING\*\*\*

**Remove any lighting or wiring that will interfere with installation of Winch Guard Tube.**

### Winch Guard Tube

Step 1 – Remove plastic plugs if any are covering holes for 3/8” Allen Bolts.

Step 2 – Place Winch Guard Tube onto bumper and align the slots with the holes in bumper.

Step 3 – Install all four 3/8” allen bolts and flat washers, then tighten to 20 ft. lbs torque.

Step 4 – Press in 6 supplied plastic wire guides into drilled holes. If installing offroad lights you can run the wire on top of the wire guides and use zip tie to hold wire.



#### **Attention**

Installation instructions provided must be read and followed exactly when installing product. Failure to do so could potentially result in injury or death of any occupants in the vehicle. **WEAR SEAT BELTS AT ALL TIMES WHEN DRIVING!**

Though our products are rugged, they are primarily designed and built to enhance the appearance of the vehicle and will not protect from death or injury in the event of an accident. Adhere to all vehicle manufacturers specifications.