



Proudly Made In USA

Installation Instructions:
JL Summit Winch Guard
Part Number: **600.100.150**

Vehicle Fitment:
Fits onto JL Series Front
Summit Modular Bumpers

Parts List

Qty:

- 1 Tube Winch Guard
- 4 Stainless 3/8-16 Button Head Screws
- 4 Stainless Flat Washers
- 4 Black Plastic Wire Guides

Tools Needed



7/32" Hex
Wrench

Congratulations on your purchase of the Hyline Offroad JL Summit Series Winch Guard. Our products are completely manufactured in our facility located in Perkasie, PA. They are designed and engineered for durability and long product life. We sincerely thank you for your purchase and your support. We look forward to serving you in the future.

Hyline Offroad Staff

PLEASE READ INSTRUCTIONS BEFORE BEGINNING INSTALLATION

Winch Guard Tube Installation

Step 1 – Remove plastic plugs if any are covering holes for 3/8” button head screws.

Step 2 – Place Winch Guard Tube onto bumper and align the holes with the threaded holes in bumper.

Step 3 – Install all four 3/8-16 button head screws and flat washers, then tighten.

Step 4 – Press in the 4 supplied plastic wire guides into drilled holes. If installing aftermarket lights or a light bar you can run the wire on top of the plastic wire guides and use zip tie to hold wire.



Attention

Installation instructions provided must be read and followed exactly when installing product. Failure to do so could potentially result in injury or death of any occupants in the vehicle. **WEAR SEAT BELTS AT ALL TIMES WHEN DRIVING!**

Though our products are rugged, they are primarily designed and built to enhance the appearance of the vehicle and will not protect from death or injury in the event of an accident. Adhere to all vehicle manufacturers specifications.