

PART #	DESCRIPTION
59706CP	TOYOTA S2 SECONDARY 2.5 VS RR CDCV PAIR

COMPONENTS INCLUDED	
(1) 154962CD TOYOTA S2 RR CDCV SECONDARY (DRVR) (1) 154962CP TOYOTA S2 RR CDCV SECONDARY (PASS)	(1) 59706H TOYOTA S2 HARDWARE KIT
HARDWARE INCLUDED	
59706H HARDWARE KIT	
(2) 250002 7.50 UNIVERSAL RESI MT PLATE (2) 605101 3/8-16 X 1.000 BOLT (2) 605122 3/8-16 C-LOCK NUT	(4) 605133 3/8 SAE FLAT WASHER (4) 605926-BLK 5-1/2 X 0.14 NYLON CABLE TIE (1) 611051 #40 2 1/16-3" HOSE CLAMP KIT
611051 HARDWARE KIT	
(4) 605931 1/2 X 2 1/16 - 3" ID #40 SS HOSE CLAMP	
TOOLS REQUIRED	
3/4" SOCKET / WRENCH	9/16" SOCKET / WRENCH
TECH NOTES	
<p>1. REQUIRES USE OF ICON S2 SHOCK HOOP KIT (56102).</p> <p>2. YOUR ICON SHOCK ASSEMBLIES COME FACTORY CHARGED TO 150 PSI. RELEASING NITROGEN PRESSURE MAY LEAD TO SHOCK MALFUNCTION AND REDUCED RIDE QUALITY. FAILURE CAUSED BY LOW NITROGEN PRESSURE IS NOT COVERED UNDER ICON'S WARRANTY POLICY.</p>	



WARNING!
<p>** READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED SEVERE FRAME, SUSPENSION AND TIRE DAMAGE MAY RESULT TO THE VEHICLE!</p> <p>** ICON VEHICLE DYNAMICS RECOMMENDS THAT YOU EXERCISE EXTREME CAUTION WHEN WORKING UNDER A VEHICLE THAT IS SUPPORTED WITH JACK STANDS.</p> <p>** ICON VEHICLE DYNAMICS RECOMMENDS ALL INSTALLTION TO BE PERFORMED BY A PROFESSIONAL SHOP/SERVICE TECHNICIAN. PRODUCT FAILURE CAUSED BY IMPROPER INSTALLATION WILL NOT BE COVERED UNDER ICON'S WARRANTY POLICY.</p>

INSTALLATION

REFER TO ICON (56102) 07-UP FJ/03-UP 4RUNNER/05-UP TACOMA S2 SHOCK HOOP KIT FOR FULL INSTALLATION INSTRUCTIONS.

