



Rain Guard For Injen Evolution Intake System P/N:EVO2000 Sold separately

**Part number  
EVO2000RG  
Rain Guard  
2012-2015**

**Scion/Subaru/Toyota  
FRS/BRZ/GT86  
2.0L Boxer 4 Cyl.**

- |                        |         |
|------------------------|---------|
| 1- Rain shield Guard   | X-20125 |
| 2- M6 Socket cap screw | (#6083) |
| 2- 3/8" vinyl cap      | (#8005) |
| 1- 1 page instruction  |         |

**Congratulations! You have just purchased The Injen Evolution Intake System.**

**Please check the contents of this box immediately.  
Please check the contents of this box immediately.**

**Caution:** *The installation of this rain guard does not protect the engine from ingesting water during heavy rain fall or floods. The rain guard will help deflect direct rain from entering the Injen Ram Air inlet during light rain fall. Injen Technology Ram Air Intake Systems should be removed in wet climate conditions. Failure to comply with the above warning may cause water to be absorbed into the engine through the Intake System causing serious engine failure. Injen Technology assumes no liability for damages to your engine due to water entering your engine through the Injen Technology Intake System.*



**WARNING: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE SYSTEM, ENGINE AND COMPONENTS!!!**  
**\*Do not attempt to install the intake system while the engine is hot.**  
 Severe burn could result from touching hot engine components!



Remove front bumper cover. Loosen and remove the Injen Evolution intake out of vehicle. Loosen the radiator support. (see Injen Evolution instruction sheet EVO2000) Loosen the 2 socket cap screws from bracket and 2 plastic push clips. Push Injen ram scoop down allowing for access to inserts on scoop.



Install the rain guard. Secure using provided M6 socket cap screws and tighten. Once secure, cover the socket cap screw using provided vinyl cap. This will prevent any contact with screws and front bumper support. Failure to do so will result in vibration noise.



Rain guard installation is now complete. Re-install the scoop assembly and secure the intake system. **Note: Check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.**