



Remove the entire stock exhaust from the axle back. remove the 2 bolts and springs and save for install.



Install the Injen axle back exhaust, and position to the factory flange.



Install and secure the hangars. Secure and tighten using factory springs/bolts. Secure using provided M8 nuts. Tighten and secure the exhaust. Your installtion is now complete. Check for clearance and positon for best possible fit. Thank you for choosing Injen Technology!