

INTRO-TECH AUTOMOTIVE

HOW TO INSTALL YOUR CUSTOM PREMIUM™ FOLDING AUTO SHADE



STEP 1: Unfold the CUSTOM PREMIUM™ FOLDING AUTO SHADE, and place it flat onto the dash area. Then slide it forward.



STEP 2: Lift the top of the CUSTOM PREMIUM™ FOLDING AUTO SHADE into the windshield area.



STEP 3: Pull down each sun visor to hold the CUSTOM PREMIUM™ FOLDING AUTO SHADE in place.



Drawstring storage
bag included