

INSTRUCTIONS
06-09 HUMMER H3

LEDC-346C, S
FRONT LED TURN SIGNALS



Your new IPCW L.E.D. Turn Signals are quality-made products that will work beautifully on your vehicle. Please refer to the pictures below for installation.



1. Unscrew (2) 10mm nuts above the grille on header panel.



2. Unscrew (2) more 10mm nuts located on inner side of the grille.



3. Remove the 10mm screws in the grille next to the headlights on each side.



4. Gently pull grille to unclip from the header panel.



5. Remove the grille.



6. Unscrew the 10mm nut located in upper area of stock turn signal.



7. Unscrew the 10mm nut in the lower part of headlight that is covered by a rubber piece.



8. Unscrew the 10mm nut between headlight & lower area of stock turn signal.



9. Remove the screw to release bracket.



10. Push in clip for headlight & turn signal panel and it will be released.



11. Disconnect from wire harness.



12. Disconnect the side marker.



13. Remove the entire light panel.



14. Twist & unlock socket and remove bulb.



15. Remove all (3) screws on the back of stock turn signal.



16. Remove stock turn signal.



17. Take (IPCW) L.E.D. Turn Signal out of box.



18. Place L.E.D. light onto the panel.



19. Re-screw on all (3) screws.



20. Secure screws very tightly.



21. Connect L.E.D. light to stock socket. Make sure they match (**Black wire to Black Wire**).



22. Twist & lock the socket to seal the light.



23. Make sure everything is in place before reinstalling.



24. Repeat Steps 1-16 to reinstall.



Done! **Thank you** for your purchase. We hope you enjoy your new IPCW LED Turn Signals.

Crystal Eyes™

LED TECHNOLOGY