

**INSTRUCTIONS**

**LEDT-344C, CB, CR, CS**

**00-05 MONTE CARLO**

**LED TAIL LIGHTS**

**(If your vehicle is 06-07, see reverse side for instructions.)**

Your new IPCW L.E.D. TAIL LIGHTS are quality-made products that will work beautifully on your vehicle. Please refer to the pictures below for installation.



1. Open trunk and simply remove butterfly nuts using your hand and remove stock tail light.



2. Unplug main wire harness from vehicle connector.



3. Twist & unlock all sockets from stock light.



4. Remove all 3 light bulbs from vehicle sockets.



5. Keep the wire harness for installation on the (IPCW) LED TAILLIGHTS.



6. Take (IPCW) Taillight out of box and remove protective film from lens.



7. You should have 2 male connectors from the back of IPCW taillight.



8. Plug in the top 2-wire male connector to vehicle's socket harness. Make sure to match **black wire to black wire**.



9. Plug in the bottom 3-wire male connector to vehicle's socket harness. Make sure to match **black wire to black wire**.



10. The small (194) socket would require no bulb, no wire connection, just twist & lock to seal the light.



11. Before installing make sure everything is connected & tightly sealed.



12. Now simply reconnect wire harness to vehicle factory plug and reinstall IPCW taillights on vehicle.



13. DONE! THANK YOU for your purchase . We hope you enjoy your new IPCW TAILLIGHTS.

**NOTE:**

**INSTALLING L.E.D. LAMPS**

After you have installed the new lamps, you should:

1. Test the lights to make sure all L.E.D. bulbs light up.
2. Check to make sure the Cruise Control operates (if the vehicle is equipped).