

**INSTRUCTIONS**  
**07-UP FJ CRUISER**

**LEDT-2038C,CB,CR,CS**  
**LED TAILLIGHTS**



Your new IPCW L.E.D. TAILLIGHT are quality-made products that will work beautifully on your vehicle. Please refer to the pictures below for installation.



1. Open liftgate to remove plastic covering in the cargo space.



2. Remove side storage cover above the plastic covering in Step 1.



3. Inside of side storage cover, there is another cover. Remove it as well.



4. Unscrew the 8mm bolt on each side of the hooks.



5. Remove hooks on each side.



6. Remove plastic cap & clip next to the side storage cover.



7. After removing all bolts & screws unclip side panel from the body.



8. Remove 10mm nut located on upper part of cavity.



9. Remove 10mm nut located on lower part of cavity.



10. Pull away inner plastic panel to get to the third 10mm nut.



11. Gently pull stock taillight out.



12. Remove turn & brake light bulbs.



Remove (IPCW) L.E.D. Taillight from box.



Connect 3-wire plug to 3-wire stock socket. Twist & lock to seal the light. Make sure it is sealed and the wires match **(Black to Black wire)**.



Connect 2-wire plug to 2-wire stock socket. Twist & lock to seal the light.



Twist & lock reverse light socket with stock bulb into light and seal it. Reverse Steps 1-11 to install light on vehicle. Repeat the procedures for the other side of taillight.



Done! **Thank you** for your purchase. We hope you enjoy your new IPCW LED TAILLIGHTS.

**(Show with LEDT-2038CR Ruby Red)**