

## INSTRUCTIONS

## LEDT-348C, CB, CR, CS

### 06-07 MONTE CARLO LED TAIL LIGHTS

(If your vehicle is 00-05, see LEDT-344C, CB, CR, CS for instructions.)



Your new IPCW L.E.D. TAIL LIGHTS are quality-made products that will work beautifully on your vehicle. Please refer to the pictures below for installation.



1. Open trunk and simply remove butterfly nuts using your hand and remove stock tail light.



2. Unplug main wire harness from vehicle connector.



3. Twist & unlock all sockets from stock light.



4. Remove all 3 light bulbs from vehicle sockets.



5. Keep the wire harness for installation on the (IPCW) LED TAILLIGHTS.



6. Take (IPCW) Taillight out box and remove protective film from lens.



7. Should have a 3-wire male connector coming out of rear of taillight from the bottom.



8. The top socket would require no bulb, no wire connection, just twist & lock to seal the light.



9. Take 3 wire socket, connect the bottom 3 wire plug into the socket. Be sure to match connection (**Black to Black Wires**).



10. The small (194) socket would require no bulb, no wire connection, just twist & lock to seal the light.



11. Before installing make sure everything is connected & tightly sealed.



12. Now simply reconnect wire harness to vehicle factory plug and reinstall IPCW taillights on vehicle.



13. DONE! THANK YOU for your purchase . We hope you enjoy your new IPCW TAILLIGHTS.

Crystal Eyes™