

INSTRUCTIONS

05-UP COBALT 2 DOOR

LEDT-350C, CR, CS, CB

L.E.D. TAIL LIGHTS



Your new IPCW L.E.D. TAILLIGHTS are quality-made products that will work beautifully on your vehicle. Please refer to the pictures below for installation.



1. Open trunk and remove butterfly nut & two 8mm nuts.



2. Disconnect sockets and remove stock taillights.



3. On trunk lid, unclip plastic cover to remove trunk lid lights.



4. Remove 8mm nuts & unclip lights from trunk lid.



5. Twist & unlock sockets from stock light. Do not remove reverse light bulb.



6. All your stock taillights should be removed.



7. On the back of (IPCW) taillights, there is a (large) male connector & a (small) female connector.



8. In (IPCW) box, it comes with 2 extra sets of wires a 12 ft. & 6 ft. (Gray) color. Connect to LED taillights.



9. 6 ft. wire connects to the driver side taillight & trunk lid light. 12 ft. wire connects to right side.



10. Remove bulb from stock vehicle socket.



11. Connect L.E.D. taillight male connector to vehicle stock socket. Be sure to match **(Black wire to Black wire)**.



12. After connecting (Gray) wire to LED light. Run wire thru vehicle body cavity to enter into trunk. Run wire thru the trunk carpet.



13. Twist & lock stock socket to (IPCW) Light & Install taillight.



14. After installing taillight run (gray) wire thru the carpet inside trunk to come out thru the trunk lid cavity hole.



15. Connect (IPCW) trunk lid lights with (Gray) wires, Twist & lock stock socket with reverse light bulb.



16. Reinstall (IPCW) trunk lid lights.



Zip tie (Gray) wires to stock wire harness.



Run passenger side (Gray) wires thru the inner panel of the trunk lid.



Then connect wire to the trunk lid light.



Zip tie (Gray) wires to stock wire harness & reinstall (IPCW) taillights.



Done! **Thank you** for your purchase. We hope you enjoy your new IPCW LED Taillights.

