

## INSTRUCTIONS 06-UP CHEVY HHR

## LEDT-353C, CB, CR, CS L.E.D. TAILLIGHTS



Your new IPCW L.E.D. TAIL LIGHTS are quality-made products that will work beautifully on your vehicle. Please refer to the pictures below for installation.



1. Open liftgate and remove the plastic cover the side in the cargo area.



2. Then, remove all 8mm nuts inside to release the stock tail light and keep the nuts for Step 7.



3. When stock light is released, the plastic lamp brackets inside can be removed also. Keep lamp brackets for Step 7 & 10.



4. Twist and unlock sockets to remove stock light. Remove factory bulbs as well.



5. Take (IPCW) L.E.D. Taillights out from box.



6. For the top L.E.D. tail light, plug in the light with a big LED connector to vehicle's socket making sure wires match **Black to Black.**



7. Twist & lock socket then install the LED tail light with lamp bracket kept from Step 3 and the 8mm nuts kept from Step 2. Make sure all wires go through to vehicle's body cavity.



8. Make sure to pull the extra wire into body cavity to connect to bottom L.E.D taillight in Step 11.



9. Connect the bottom L.E.D tail light to vehicle's socket. Make sure the wires match **Black to Black.**



10. Twist & lock socket then install the LED tail light with lamp bracket kept from Step 3 and the 8mm nuts kept from Step 2. Make sure all wires go through to vehicle's body cavity.



11. Connect the other wire from bottom LED tail light to top LED tail light with the wire pulled from Step 8.



12. Make sure 8mm nuts are secured. Then, repeat Steps 1 to 12 for other side.



13. Done! **Thank you** for your purchase. We hope you enjoy your new IPCW L.E.D. Tail Lights.  
(Show with LEDT-353C Crystal Clear L.E.D. Tail Lights)