

IRON CROSS AUTOMOTIVE INC.

INSTALLATION INSTRUCTIONS REAR BUMPER

05-14 TOYOTA TACOMA

21-705-07

PARTS LIST

8	1/2" FLAT WASHERS
4	1/2" LOCK WASHERS
4	1/2" HEX BOLTS
4	1/2" HEX NUTS
2	TAG LIGHTS

BUMPER REMOVAL

1. UNPLUG TAG LIGHTS FROM BUMPER SOCKET.
2. REMOVE PLASTIC CAPS TO EXPOSE (2) BOLTS AND REMOVE.



THIS PRODUCT IS FOR OFFROAD USE ONLY. ALL LIABILITY FOR INSTALLATION AND USE RESTS WITH THE OWNER.
CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE.