



Installation Instructions and Warranty Information

Part# 1811S 2008-2009 Pontiac G8 6.0L V8



This Product has been granted a California Air Resources Board (CARB) "E.O" (Executive Order) Exemption, or is considered a Direct Replacement or Consolidated Replacement part. It is 50 State Legal when installed on the appropriate vehicle per the Manufacturer Application guide and Installation Instructions.

Read all instructions carefully before attempting installation.

PerTronix© thanks you for choosing JBA [HEADERS](#), the best fitting, highest quality header on the market. In order to realize the full potential of our good fit, please read and understand these instructions completely prior to starting work.

Check to make sure you received the proper parts for your application. The header number will be stamped on the engine flange. If you are unsure you have received the proper parts call before you start work.

Be sure to work safe! Whenever you work under the vehicle be sure that it is located on level, solid ground and is supported by adequate safety stands! Remember: Hot asphalt will not support most jack stands!

Many factors affect the installation of headers, some of which are broken or aftermarket motor mounts, accidents that impact the configuration of the frame, and/or the installation of different engines or aftermarket cylinder heads.

Attention Customers breaking in new engines: Due to the extreme heat generated during the break-in process, the appearance of the ceramic coating may be altered in certain areas. The protection characteristics and thermal barrier properties of the coating is never compromised. It is recommended that a cast iron manifold or old set of headers be used for this process.

Notice: The coating of these headers can be marred or scratched during installation. If the header needs to be returned and is damaged, you will be charged for recoat.

JBA uses sealing beads on all its headers. We have found that when installed correctly, the raised bead around each port increases the pressure exerted on the gasket directly adjacent to the port and effectively prevents leaking gaskets. It is normal for the flange to be raised off the cylinder head the thickness of the sealing bead. It is important when installing the header, to install all bolts loosely, then tighten evenly to ensure the flat installation of the flange. The torque sequence from one flange to another will vary, but generally every bolt on a header should be first fit snug, starting from the inside of the flange working out, alternating from top to bottom so that the bolt connects the flange to the manifold to the point where they barely touch. Second, using the same inside-out pattern, tighten each bolt until finished. This method will help prevent leakage and will give the user the best possible performance out of their pair of headers.

1. Place vehicle in a location where the floor is solid and flat, with adequate lighting. Do not attempt to work on a hot engine. Heat causes metal to expand and makes removal of fasteners difficult at best. Disconnect the battery cables from the battery. Raise the front of the vehicle to obtain adequate access to the bottom exhaust manifold flanges. Use large-base jack stands to support the vehicle. Do not rely on the jack! Block the tires to prevent the vehicle from rolling off the jack stands.
2. Spray WD-40 or some type of penetrating oil on all accessible fasteners and fittings before attempting to remove them.
3. From underneath the vehicle, remove nuts attaching the manifolds to the exhaust pipe.
4. Remove bolt attaching steering shaft to steering rack. Slip shaft off of rack.
5. From above, remove bolt attaching oil dipstick to head. Dipstick will pivot out of the way.
6. Carefully remove spark plug wires. Twist boot prior to tugging on them. Do not pull directly on the wire. Remove spark plugs.
7. Remove bolts attaching manifolds to head. Remove manifolds.
8. Clean gasket surface, be careful not to gouge the head.
9. Install headers using gaskets and supplied hardware.
10. Re-install spark plugs, and plug wires. Re-attach dipstick using spacer provided.
11. From underneath, connect headers to exhaust pipes, placing a flat washer over the stud, and re-using factory nuts. Re-connect steering shaft, and secure.
12. Check Check to ensure there is adequate clearance on all fuel lines, brake lines, battery cables, wire harnesses, etc.
13. Re-check everything!
14. Start engine, check for leaks and test drive. Then let engine cool and re-torque header bolts.
15. Periodically check and retighten header bolts.

Parts List:

- (1) Driver 's Side Header Assembly
- (1) Passenger 's Side Header Assembly
- (2) Head flange gaskets
- (12) 8mm-1.25 x 25mm Header fasteners w/lock washers (Torque to 13 ft./lbs)
- (4) 3/8 -16 x 2" Collector bolts w/nuts and washers (Torque to 35 ft./lbs)
- (1) Dipstick tube spacer
- (1) CARB EO Sticker (to be placed underhood to assist with CA Smog Check)

LIMITED ONE YEAR WARRANTY

All JBA HEADERS and exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.

JBA
performance**exhaust**®