

JBA[®]

performance exhaust

INSTALLATION INSTRUCTIONS

** Installation recommendation: JBA recommends in most case that the vehicle be taken to a reputable [exhaust](#) shop for installation.

40-2686

2015 Mustang 5.0 GT
Axle Back

Parts List:

P/S Muffler/Tip assembly 1
D/S Muffler/Tip assembly 1
accu Seal Clamps 2

Recommended Tools:

Pry Bar
Ratchet
15mm deep socket
Large channel lock pliers
Sawzall, pipe cutter, or Hacksaw
WD40



Start:

1. Remove and inventory the JBA Exhaust System.

2. Measure 5" from the middle of the bend as shown in the picture. Mark a line. This is where you will cut the stock mufflers off the mid pipe. Shown with the mid pipe on the ground but you can do this in the car. Cut the pipes being careful to keep the cut square.



5. Adjust the tips an equal distance from the bumper cover. You may need to use a pry bar and bend the hangar rods slightly. When you are satisfied with the placement, tighten the clamps securely.



3. Using pliers or a pry bar, slide the rubber hangers from the hangar rod on the muffler and tailpipe (a little WD40 helps). Remove the mufflers from the car

4. Slip a provided clamp over each section of the midpipe. Slide the JBA muffler/tip assemblies over the mid pipe and the hangers into the rubber isolators on each side. WD40 or similar will make this easier.

6. Using a soft cloth, wipe the new JBA tips clean.



JBA recommends taking the vehicle to a muffler shop and having all slip connections tack welded.