

JBA[®] performance exhaust

INSTALLATION INSTRUCTIONS

** Installation recommendation: JBA recommends in most case that the vehicle be taken to a reputable exhaust shop for installation.

40-3053

2015-17 Chevy Colorado 2.5/3.6L

Parts List

Qty.

- | | |
|---|---|
| 1 | Over Axle Pipe /Tail Pipe with Chrome Tip |
| 1 | Intermediate Pipe |
| 1 | Muffler |
| 2 | ACCU-Seal Clamps |
| 1 | Stainless Clamp |
| 1 | U-Bolt Clamp with hangars |

JBA Performance Also manufactures Cat4Ward Exhaust Headers for your Vehicle.



PerTronix© thanks you for choosing JBA Performance Exhaust, the best fitting, highest quality header's and exhaust on the market. In order to realize the full potential of our good fit, please read and understand these instructions completely prior to starting work.

Check to make sure you received the proper parts for your application. Check the parts received against the parts list above. If you are unsure you have received the proper parts call before you start work.

Be sure to work safe! Whenever you work under the vehicle be sure that it is located on level, solid ground and is supported by adequate safety stands! Remember: Hot asphalt will not support most jack stands!

Many factors affect the installation of exhaust, some of which are broken or aftermarket motor mounts, accidents that impact the configuration of the frame, and/or the installation of different engines, headers, spare tire sizes, lift and lowering kits, and trailer hitches.

Allow the vehicle to fully cool before attempting installation, hot exhaust can and will burn you !

Removal;

1. Remove the stock exhaust. In many cases it will be easier to cut the stock exhaust pipe behind the muffler before it goes over the axle.
2. Disconnect the stock hangers from the Rubber insulators, a bit of WD40 will help get the isolators off. The rubber insulators will be reused, leave them hanging on the truck. Remove the tail pipe.
3. Unbolt the muffler inlet from the catalytic converter, disconnect the hangers from the rubber insulators and remove the muffler.

Installation;

1. Install the intermediate pipe to the catalytic convertor pipe using the hardware.
2. Slip the muffler onto the intermediate pipe using one of the supplied accu-seal clamps.
3. Slip the over axle pipe into the muffler using one of the Accu-seal clamps .Slide the tailpipe hangers into the stock rubber isolator, WD40 or similar will make this easier. Take the U-Bolt clamp with hanger apart and slip it over the pipe just behind the muffler. Install the two hangars into the stock rubber isolators.
4. Slip the JBA Stainless Tip onto the overaxle pipe using the Stainless clamp. Adjust the Tail Pipe,/Over Axle pipe and Chrome Tip so that they clear all body, frame, and suspension parts. JBA recommends that the tip be at least 1/2" away from the lower body panel.
5. Once you are happy with all the clearances, tighten all the JBA clamps to 40 lbs. ft. (except the stainless tip clamp, tighten that to 15 ft. lbs.) We recommend that you tack weld the connections once you are happy with the fit and have taken it for a test drive to check for leaks.
6. JBA recommends that you inspect and retighten all clamps after 50 miles.



WARNING

This product can expose you to chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm.

JBA recommends taking the vehicle to a muffler shop and having all slip connections tack welded.