



## **JET Power-Flo**

### **Throttle Body Spacer Installation Instructions 2000-01 Dodge Dakota/Jeep 4.7L Part #62114**

- 1. Remove throttle body cover and air intake assembly from the throttle body.**
- 2. Remove the throttle cables and the bolts that mount the throttle linkage to the intake manifold.**
- 3. Remove the 3 bolts that mount the throttle body to the intake manifold.**
- 4. Install the JET Power-Flo throttle body spacer using the supplied o ring.**
- 5. Replace the 3 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.**
- 6. Install the 3 throttle linkage extension plates using the supplied allen head screws and reinstall the throttle linkage to the plates.**
- 7. Install 2 linkage extension plates using the supplied allen head screws to relocate the throttle body cover.**
- 8. Verify that the throttle linkage, cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some instances it may be necessary to readjust the cables for proper travel - refer to your factory service manual for correct adjustment procedures.**
- 9. Reinstall the air intake assembly.**