



JET Power-Flo
Throttle Body Spacer Installation Instructions
2004-2006 Ford 4.0L
Part #62142

1. Remove Air Intake Assembly from throttle body.
2. Remove the 4 bolts that mount the throttle body to the intake manifold
3. Remove the gasket and clean any residue from the surfaces. Be careful not to get any gasket material in the intake manifold.
4. Install the JET Power-Flo throttle body spacer using one gasket between the intake manifold and the spacer and one gasket between the throttle body and the spacer.
5. Replace the 4 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.
6. Verify the throttle is NOT binding and that the travel on the linkage is correct before you start the vehicle. **NOTE:** In some applications it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.
7. Reinstall the Air Intake assembly.