



JET Power-Flo
Throttle Body Spacer Installation Instructions
General Motors
3.6 L Engines

Part #62165

- 1. Remove the air intake assembly and from throttle body.**
- 2. Remove the 4 bolts that mount the throttle body to the intake manifold**
- 3. Install the JET Power-Flo throttle body spacer using the new gaskets, placing one gasket on each side of the spacer.**
- 4. Replace the 4 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.**
- 5. Verify that the throttle body is securely tightened and that you have reattached any electrical plugs or hardware that you had to remove with the throttle body.**
- 6. Reinstall the Air Intake assembly.**