



Throttle Body Spacer Installation Instructions

Acura / Honda 2.4L

Part # 62185

1. Remove air intake assembly from the throttle body.
2. Remove the throttle cables and the bolts that mount the throttle linkage to the intake manifold. (If you have an electronic throttle body skip this step)
3. Remove the four (4) bolts that mount the throttle body to the intake manifold.
4. Install the JET Power-Flo throttle body spacer using the included gasket between the throttle body and the spacer.
5. Replace the four (4) bolts that mount the throttle body to the intake manifold using the new bolts, lock washers and flat washers supplied in the kit.
6. Verify the throttle linkage ,cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures. (If you have an electronic throttle body skip this step)
7. Reinstall the Air Intake assembly and reconnect any vent hoses you removed.

Parts included List

- 1- **JET Powr-Flo** Spacer
- 1- Gasket
- 4- m8 x 90mm hex bolts
- 4- m8 washers
- 4- m8 lock washers

NOTE: Some aftermarket air intakes may need to be modified to work with the added thickness of the JET Powr-Flo spacer.