



## GM Mass Air Flow Installation Instructions Part #69137

1. Locate the factory Mass Air Flow sensor located in the air intake tube of the vehicle.
2. Remove the two screws that mount the factory Mass Air Flow Sensor to the air intake tube.
3. Install the JET Powr-Flo Mass Air Sensor in the intake tube using the factory screws that you previously removed.
4. Start vehicle and verify that the check engine light is not on.
5. Put your factory sensor away in a safe place for a spare.