



Part Number 69143

Fits the following vehicles



2006-2007	Buick Rainer	4.2L
2007-2008	Cadillac SRX	4.6L
2007-2008	Cadillac STS	4.6L
2006-2008	Cadillac STS-V	4.4L
2006-2008	Cadillac XLR-V	4.4L
2005-2008	Chevrolet Cobalt	2.0, 2.2, 2.4L
2007	Chevrolet Colorado	2.9, 3.7L
2006-2007	Chevrolet Corvette Z06	7.0L
2006-2008	Chevrolet HHR	2.2, 2.4L
2006-2007	Chevrolet Trailblazer	4.2L
2007	GMC Canyon	2.9, 3.7L
2006-2007	GMC Envoy	4.2L
2007	Hummer H3	3.7L
2006-2007	Isuzu Ascender	4.2L
2007	Isuzu I-370	3.7L
2007-2008	Pontiac G5	2.2, 2.4L
2005-2006	Pontiac Pursuit	2.2, 2.4L
2006-2008	Pontiac Solstice	2.0, 2.4L
2005-2007	Saturn ION	2.2, 2.4L
2007-2008	Saturn Sky	2.0, 2.4L
2007-2008	Saturn Vue	2.4L

Installation Instructions

1. Locate the factory Mass Air Flow sensor located in the air intake tube of the vehicle.
2. Remove the two screws that mount the factory Mass Air Flow Sensor to the air intake tube.
3. Unplug the wiring connector from the factory Mass Air Flow Sensor
4. Install the Jet Powr-Flo **Mass Air Flow Sensor** in the intake tube using the factory screws that you previously removed. Plug the factory wiring connector into the new sensor.
5. Start the vehicle and verify that the check engine light **IS NOT ON!**
6. Put your factory sensor away in a safe place. Do not discard your original sensor.