



Part Number 69180

Fits the following vehicles

2012-2013	Buick	Regal	2.0, 2.4L
2012-2013	Cadillac	CTS	3.0L
2012-2013	Cadillac	SRX	3.6L
2012-2013	Chevrolet	Camaro	3.6L
2012-2013	Chevrolet	Equinox	2.4,3.0L
2012-2013	Chevrolet	Impala	3.6L
2012-2013	Chevrolet	Traverse	3.6L
2012-2013	GMC	Acadia	3.6L
2012-2013	GMC	Terrain	2.4, 3.6L



Installation Instructions

1. Locate the factory Mass Air Flow sensor located in the air intake tube of the vehicle.
2. Remove the two screws that mount the factory Mass Air Flow Sensor to the air intake tube.
3. Unplug the wiring connector from the factory Mass Air Flow Sensor
4. Install the Jet Powr-Flo Mass Air Flow Sensor in the intake tube using the factory screws that you previously removed. Plug the factory wiring connector into the new sensor.
5. Start the vehicle and verify that the check engine light **IS NOT ON!**
6. Put your factory sensor away in a safe place. Do not discard your original sensor.