



# Part Number 69190

## Fits the following vehicles

2004-2007	Ford E-150-350	4.6, 5.4, 6.8L
2004-2007	Ford F-150	5.4L
2004-2007	Ford F-250	5.4, 6.8L
2004-2007	Ford F-350	5.4, 6.8L
2005-2007	Ford Escape	2.3L
2005-2006	Ford Expedition	5.4L
2006	Ford Explorer	4.0, 4.6L
2006-2007	Ford Fusion	2.3, 3.0L
2005-2007	Ford Five-Hundred	3.0L
2005-2007	Ford Mustang	4.6L
2004-2007	Ford Ranger	2.3, 3.0, 4.0L
2007	Lincoln MKZ	3.5L
2005-2007	Lincoln Navigator	5.4L
2006-2007	Lincoln Zephyr	2.3, 3.0L
2005-2007	Mercury Mariner	2.3L
2006-2007	Mercury Milan	2.3, 3.0L
2005-2007	Mercury Montego	3.0L



## Installation Instructions

1. Locate the factory Mass Air Flow sensor located in the air intake tube of the vehicle.
2. Remove the two screws that mount the factory Mass Air Flow Sensor to the air intake tube.
3. Unplug the wiring connector from the factory Mass Air Flow Sensor
4. Install the Jet Powr-Flo **Mass Air Flow Sensor** in the intake tube using the factory screws that you previously removed. Plug the factory wiring connector into the new sensor.
5. Start the vehicle and verify that the check engine light **IS NOT ON!**
6. Put your factory sensor away in a safe place. Do not discard your original sensor.