



FLAT STYLE SMALL BLOCK FORD WHEELS FOR USE WITH GM TRANSMISSION

FOR USE WITH: Old Style (flat) Small Block Ford Flexplates with Twelve (12) center holes

PARTS REQUIRED: 80015 – Bolt on Crank Adapter AND 80002-1 – Sleeve Adapter for use with 80015



This is the 80015 adapter, notice the slight taper on the OD, it should taper down to 1.838"-1.842". This will accept the small OD of the 80002-1 sleeve adapter.



This is how the 80002-1 sleeve adapter fits into the 80015 crank adapter. This can usually be pushed in by hand or tapped in with a rubber mallet, you will feel it seat itself.



This is how it should look when done, the sleeve adapter portion will protrude thru the center hole of the flexplate towards the converter side, the I.D. of this will accept the 1.702 OD of any standard GM converter pilot. This is ready to be installed on the flexplate.

Learn more about performance engine parts we have.