



*Installation Instructions for
Front Light Bars K C7400, 7401, 7402
Fits 97-06 Jeep Wrangler*

Follow these simple instructions to mount your new KC HiLiTES Front End Lite Bar.

1. Using a #55 Torx bit, remove the bolts holding the two tow hooks. (see photo) ***NOTE - Some vehicles may not have tow hooks, but the same bolts will be used.***
2. Align the KC bar mounting plate with the tow hook bolt holes, place the tow hooks on top of the bar mounting plate, re-insert the bolts and tighten securely.
3. You're DONE. You may now mount the KC lights of your choice.

