



## INSTALLATION INSTRUCTIONS

**PART No.** 30404-30435

**MODEL No.**

Place the rear corner guard in place and align the bottom edge of the guard with the body tub. Mark the two mounting holes with a magic marker. Center punch the mark, then drill with a small drill bit. Re-drill the holes using an 1 1/32" drill bit. Bolt the corner guards in place using the stainless steel bolts provided.

### TOOLS REQUIRED

Electric drill

Assorted drill bits

.5" Wrench or .5" Socket and ratchet

Hammer and center punch



## INSTALLATION INSTRUCTIONS

**PART No.** 30404-30435

**MODEL No.**

Place the rear corner guard in place and align the bottom edge of the guard with the body tub. Mark the two mounting holes with a magic marker. Center punch the mark, then drill with a small drill bit. Re-drill the holes using an 1 1/32" drill bit. Bolt the corner guards in place using the stainless steel bolts provided.

### TOOLS REQUIRED

Electric drill

Assorted drill bits

.5" Wrench or .5" Socket and ratchet

Hammer and center punch

