



OILING INSTRUCTIONS

K&N® Airforce Pre-Cleaner

This K&N Airforce Pre-Cleaner must be oiled before using. Use K&N® Recharger® kit 99-5000 or 99-5050.

INSTRUCTIONS:

OILING:

1. Saturate the K&N® Airforce Pre-Cleaner with K&N® filter oil.
2. Massage until it is fully covered.
3. Squeeze, do not wring the excess oil from the K&N Airforce Pre-Cleaner.
4. Install the K&N Airforce Pre-Cleaner on the K&N® air filter per the installation instructions.

CLEANING:

1. Remove the K&N Airforce Pre-Cleaner from the K&N air filter.
2. Spray K&N air filter cleaner until it completely saturates the pre-cleaner.
NOTE: Allow cleaner to soak 10 minutes to loosen the dirt. Do not let cleaner dry on the pre-cleaner.
3. Rinse off pre-cleaner with cool low-pressure water. Continue to rinse until all traces of cleaner are gone. If it is extremely dirty it may be necessary to repeat steps 1 and 2. If there are spots of dirt remaining, spray each spot directly with cleaner, allow a few minutes for it to soak and repeat rinsing step.
4. After rinsing, gently shake off excess water and allow to dry naturally. Do not proceed to the oiling step until it is completely dry.

CAUTION: THE USE OF ANY OTHER DRYING METHODS (I.E. COMPRESSED AIR, DRYER HEATERS, HEAT GUNS) COULD DAMAGE FILTER.

5. Apply K&N air filter oil liberally to the pre-cleaner.
 - A. If using a K&N squeeze bottle, squeeze bead of oil along the crown of each pleat using the lip on the squeeze bottle tip as a guide. Utilize graduated view strip on bottle to dispense proper amount of oil.
 - B. If using a K&N aerosol spray, spray an even amount of oil along the crown of each pleat.
NOTE: Wait 20 minutes for the oil to be absorbed into the pre-cleaner.