



Part Number 57-0417

INSTALLATION INSTRUCTIONS

Vauxhall Astra MK4 2.0L Turbo 2000-2004

Opel Astra G 2.0L turbo 2000-2005

1. Unclip the CCSV (carbon canister solenoid valve) from the air box lid. (Fig 1)
2. Unclip the intake hose from the air box lid. (Fig. 2)
3. Unclip and remove the air box lid from the vehicle.
4. Remove the torx screw and carefully remove the air box base from the vehicle. (Fig. 3)
5. Remove the air box feed pipe from the vehicle. (Fig. 4)
6. Secure the CCSV to the air box-mounting bracket using the plastic tie supplied. (Fig. 5)
7. Assemble the 'L' bracket and saddle bracket as shown using the tapered screw, conical washer, flat washer and nylock nut supplied. (Fig. 6)
8. Fit the 'L' bracket assembly to the front bolt on the side engine mounting and firmly tighten the bolt. (Fig. 7)
9. Assemble the Air filter, aluminum adaptor, silicon adaptor & metal tube using the hose clips supplied, leave the #48 hose clip loose. (Fig. 8)
10. Fit the Air filter assembly into the intake hose and secure using the original hose clip. (Fig. 9)
11. Fit the Air filter assembly into the saddle bracket and firmly tighten the #48 hose clip around the saddle bracket and silicon adaptor. (Fig. 10)
12. Carry out a final height / alignment check of the kit fitment. Installation is now complete.

Parts list:

- 1 x Air filter
- 1 x #72 Hose Clip.
- 1 x Metal Tube.
- 1 x aluminum Adaptor.
- 1 x Silicon Adaptor.
- 1 x literature Pack.

1 x Fixing Kit: -

- 1x Saddle Bracket.
- 1 x Black "L" Bracket.
- 1 x Flat Metal Washer.
- 1 x Nylock Nut.
- 1 x Black Conical Washer.
- 1 x Countersunk Bolt.
- 1 x Long Plastic Tie.
- 1 x #44 Hose Clip.
- 1 x #48 Hose Clip

WARNING: Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.

FILTER MAINTENANCE: K&N suggests checking the filter periodically for excessive dirt build-up. When the element becomes covered in dirt (or once a year), service it according to the instructions on the Recharger service kit available from your K&N dealer, part number 99- 5003EU.



Fig. # 1



Fig. # 9



Fig. # 10