

BMW 520i/528i N20 F10/11/07GT 2011-2017

Installation Instructions

1. Remove the cross member to access the air filter housing. (Fig. 1)
2. Loosen the hose clamp and remove the intake tube from the air filter housing. (Fig. 2)
3. Loosen the hose clamp and remove intake tube from the vehicle. (Fig. 3)
4. Unclip the air filter housing and remove the paper air filter from the air filter housing. (Fig. 4)
5. Fit the K&N air filter into the air filter housing and refit the original air filter housing lid. (Fig. 5)
6. Fit the provided silicone sleeve onto the air filter housing using the hose clamps supplied. (Fig. 6)
7. Fit the new K&N intake tube into the turbo inlet hose using the original hose clamp (do not fully tighten the hose clamp at this point). (Fig. 7)
8. Fit the new K&N intake tube into the air box sleeve (do not fully tighten the hose clamp at this point). (Fig. 8)
9. Align the intake assembly for proper clearance on all sides and secure all hose clamps. Refit the cross member. (Fig. 9)



Fig.#1



Fig.#2



Fig.#3



Fig.#4



Fig.#5



Fig.#6



Fig.#7



Fig.#8



Fig.#9