

INSTALLATION INSTRUCTIONS



Instruction No.

KWautomotive

685 10 151 INSTALLATION INSTRUCTIONS Cancellation kit

nstallation Instru	ictions	KW automotive
Instruction No.	685 10 151	
Front axle:	Run the standard damper control wire dard connector into the electronic com cable ties on the cable wire harness	to the supplied electronic component connector. Insert the sta ponent connector until it locks. Fix the electronic component w
1-		

Installation Instructions			KW automotive
Instruction No.	685 10 151		
Rear axle:			
	tronic component conr	ed electronic component connector. Insert the ector until it locks. Fix the electronic compone	