



# CANCELLATION KIT



<b>Installation Instructions</b>		<i>KW automotive</i>	
Instruction No.	685 10 426	Date	16.07.2015

# *KW automotive*

**685 10 426**  
**INSTALLATION INSTRUCTIONS**  
**Cancellation kit**  
[Performance Coilover Kits](#)

Installation Instructions			KW automotive	
Instruction No.	685 10 426		Date	16.07.2015
<b>Front axle:</b>		Mount the front axle electronic kit with the supplied edge clips on the chassis edge. Run the standard damper control wire to the supplied electronic component connector. Insert the standard connector into the electronic component connector until it locks.		
Right vehicle side.				



Installation Instructions			KW automotive	
Instruction No.	685 10 426		Date	16.07.2015

**Rear axle:**

Mount the rear axle electronic kit with the supplied edge clips on the chassis edge. Run the standard damper control wire to the supplied electronic component connector. Insert the standard connector into the electronic component connector until it locks.

