

POWER STEERING EVAC KIT

WARNING:

 Wear eye protection.



Includes

- 1 - Lid #1
- 2 - Lid #2
- 3 - Vapor fluid separator canister
- 4 - Plug (Small)
- 5 - Plug (Large)
- 6 - Tube, 3.5"
- 7 - Tube, 17"
- 8 - Brake Adapter x3



Fig A

1. After repairs have been completed, fill the power steering fluid to the recommended level and install appropriate stopper for the reservoir. (The type of reservoir will determine which stopper is used).
2. The vapor fluid separator canister needs to be installed in line in case any fluid is drawn from the reservoir (Fig A).
3. Pull a maximum of 20 inches of vacuum. Leave for 2 minutes to see if level drops to check for leaks (If the vacuum level stays consistent then there are no leaks).
4. With the front of the car lifted, the vacuum applied and engine not running, turn the wheels back and forth lock to lock 10 times.
5. Remove the stopper and check the fluid level making sure it is full. Start the vehicle listening for noise in the pump.
6. If the noise continues and / or the fluid Level continues to drop, repeat steps 4-6.
7. Once the fluid level remains full and there is no more noise from the pump, then the job is complete.



Kit assembled