



QUALITY... PLAIN & SIMPLE®

1964 - 1970 Mustang Brake & Clutch Pad Installation Instructions
Part # BAG-6121, BAG-6123, BAG-6125,
XBAG-6121, XBAG-6123, XBAG-6125

1964 - 1970 Mustang Brake & Clutch Pad Installation Instructions

Part # BAG-6121, BAG-6123, BAG-6125, XBAG-6121, XBAG-6123, XBAG-6125

STOP! Please read all installation instructions before beginning installation.

WARNING: Disconnect the battery before beginning installation. Make sure the vehicle is in Park and at least one tire is scotched to prevent the vehicle from moving.

Mustang Brake & Clutch Pad Installation

- Step 1:** Remove the stock rubber cover from the clutch or brake pedal. **Photo 1**
- Step 2:** Position the new Lokar aluminum cover on the stock clutch or brake pad. Make sure pad is set on so that the lip on the backside of the pedal is even all the way around the pedal.
- Step 3:** We recommend using a transfer punch that is 3/16 in diameter to get an accurate punch mark for drilling. **Photo 2** **Note:** If only a center punch is available, you can use it. However, be sure marks are centered in the hole.
- Step 4:** Double check your marks. Remove pad and drill the steel pad using a 3/16 diameter drill. **Photo 3.** Be sure holes are deburred before using supplied stainless hardware.
- Step 5:** Set pad back on and use supplied 10/32 countersunk screws and nylocks and attach as seen in **Photo 4.** **Note: Do not over tighten.**

Step 6: Glue in the end rubber using the supplied 3M™ Glue in kit. **Note:** Read glue manufacturer instructions for proper application. If excess glue gets on aluminum, clean it off with Goo-Gone™ before glue dries. **Photo 5**

Step 7: The Lokar pads are now installed and will complement the Lokar Throttle Pedal Assembly. **Photo 6**

Photos 1 - 6 **Mustang Brake and Clutch Pads**



Photo 1



Photo 2



Photo 3



Photo 4



Photo 5



Photo 6



QUALITY... PLAIN & SIMPLE®

1964 - 1970 Mustang Brake & Clutch Pad Installation Instructions
Part # BAG-6121, BAG-6123, BAG-6125,
XBAG-6121, XBAG-6123, XBAG-6125

1964 - 1970 Mustang Brake & Clutch Pad Installation Instructions

Part # BAG-6121, BAG-6123, BAG-6125, XBAG-6121, XBAG-6123, XBAG-6125

3M

Disclosure Statement For Glue Kit

DANGER! Extremely flammable liquid and vapor. Vapors may cause flash fire. May cause eye, skin, nose and throat irritation and may affect the central nervous system causing dizziness, headache or nausea. Intentional misuse by deliberately concentrating and inhaling the contents may be harmful or fatal. Contains chemicals which can cause cancer.

Contains: Methyl Ethyl Ketone, Aliphatic and Aromatic Hydrocarbons, Toluene, Carbon Black, Formaldehyde.
Precautions: Vapors may ignite explosively. Keep away from heat, sparks, open flame, pilot light and other sources of static discharge. Extinguish all flames and pilot lights, and turn off stoves, heaters, electric motors and other sources of ignition during use and until all vapors are gone. Do not smoke when using this product. Use only with adequate ventilation. Prevent vapor build-up by opening doors and windows. Ensure fresh air entry during application and drying. Store at temperatures below 120°F (49°C). Avoid eye and skin contact. Avoid breathing vapors. Wash thoroughly after handling. Close container after each use.

KEEP OUT OF REACH OF CHILDREN.

Suggested First Aid: **Eye Contact:** Flush eyes with large amounts of water. If signs/symptoms persist, get medical attention. **Skin Contact:** Remove contaminated clothing and shoes. Immediately flush skin with large amounts of water. Get medical attention. Wash contaminated clothing and clean shoes before reuse. **Inhalation:** Remove person to fresh air. If signs/symptoms develop, get medical attention. **If Swallowed:** Do not induce vomiting. Give victim two glasses of water. Never give anything by mouth to an unconscious person. Get medical attention.