



QUALITY... PLAIN & SIMPLE®

Lokar Oval Billet Aluminum Interior Door Handles
Handles Cutting Templates

General Installation Notes:

Please read the instructions completely before beginning the installation. If you have any questions please call.

Before beginning the installation, disconnect the negative battery cable and use wheel chocks to block the vehicle's wheels.

NOTE: Before cutting out the templates, double check the length and width measurements to make sure they match the dimensions listed.

The templates represent the back side of the door handles. When placed on the door panel, the printed side of the template should be facing towards the interior of the door, away from the interior of the vehicle.

Lokar Oval Billet Aluminum Interior Door Handles Cutting Templates

Building American Quality... With A Lifetime Warranty!®

