



#### Basic Brake Line Installation Tips:

1. Pre-Install kit before painting frame
2. Attach frame tabs after locating hard lines to eliminate or reduce field made double flares
3. Attach Adel® clamps after hard lines are installed
4. Check all connections for leaks. **Field Flares MUST be double flare type**

