



LVT-3120

2019-Current Dodge Ram* * Fits New Body Style from Mid-2019 and with or with out under mirror camera or puddle lights Mounting Kit: KLV-3110C





Jeep

TOYOTA

LVT-4000

Toyota Sequoia 2001-2007 Toyota Tundra 2000-2006 Mounting Kit: KLV-4010



LVT-3100A

Dodge Ram 1500 1998-2002 Dodge Ram 2500 Light Duty 1998-2002 Dodge Ram 3500 Light Duty 1998-2002 Dodge Durango* 1998-2000 Dodge Dakota* 1998-2000 Dodge Full Size Van 2000-2003 *Will Not fit 5x7 Sport. Only fits 6x9 Mounting Kit: KLV-3110A



LVT-3200

Jeep Cherokee 1984-1996 Jeep Comanche 1984-1996 Mounting Kit: KLV-3210





LVT-3100C

2009-2019 Dodge Ram* *Fits 2019 Old Body Style to Mid 2019 and with or without under Lighting Features Mounting Kit: KLV-3110C





DODGE

LVT-3100B

Dodge Ram 1500 2003-2008 Dodge Ram 2500 Light Duty 2003-2008 Dodge Ram 3500 Light Dutry 2003-2008 Mounting Kit: KLV-3110B



LVT-3300A

Dodge Caravan 1996-2000 Chrsler Town & Country 1996-2000 Plymouth Voyager 1996-2000 Mounting Kit: KLV-3310A





LVT-3000

Dodge Pickup 1994-1997 Dodge Dakota 1994-1997 Dodge Ram Pickup* 1986-1995 Dodge Van* 1986-1995 *Fits Electric and Manual. *Van 1994-1996 Chrome Only Mounting Kit: KLV-3010







LVT-3400A

Jeep Grand Cherokee 1999-2004 Jeep Wagoneer 1999-2004 Mounting Kit: KLV-2210





LVT-3400

Jeep Grand Cherokee Jeep Wagoneer Mounting Kit: KLV-3410



1993-1998

1993-1998



LVT-3100

1994-1997 Dodge Dakota* Dodge Ram Pickup 1994-1997 Dodge Van* 1994-1997 Dodge Dakota * 1996-1997 Dodge Pickup** 1996-1997 *Fits Black Electric and Manual OEM Mirror. Will Not fit 5x7 Sport **Fits Chrome Model Mounting Kit: KLV-3110







LVT-2300C

F-150 2015-Current Mounting Kit: KLV-2310C









LVT-2200A

Ford Explorer** 1997-2003
Ford Sport Trac 1997-2003
Ford Ranger* 1996-2003
Mercury Mountaineer 1996-2001
Mazda B-3000 1994-2001
Mazda B-4000 1994-2001
*Check Mirror to Match OEM Picture
**Model will not fit puddle light or
Power Mirror design





LVT-2500

Ford Club Wagon (Van) 1992-2003 Ford Econoline (Van) 1992-2003 Mounting Kit: KLV-2510



LVT-2100

F-250* 1992-1998 F-350* 1992-1998 F-150* 1992-1997 Ford Ranger* 1992-1997 Ford Aerostar 1990-1997 Ford Bronco* 1992-1996 *Fits Design for Plastic OEM Mirror Mounting Kit: KLV-2110





LVT-2300B

F-150 2009-2014 Mounting Kit: KLV-2310B





LVT-2600

F-250 Light Duty** 1999-2004
F-350 Light Duty 1999-2004
F-450 Light Duty* 1999-2004
Ford Excursion 1999-2005
*Fits Design for Chrome OEM Mirrror
**Check Mirror to Match OEM Picture
Mounting Kit: KLV-2610





LVT-2400

F-150* 1997-2001 F-250* 1997-1998 F-350* 1997-1998 *Fits Design for Manual OEM Mirror Mounting Kit: KLV-2410





LVT-2200

Ford Explorer 1988-1996
Ford Ranger* 1988-1996
Mazda Navaho 1988-1995
*Check Mirror to Match OEM Picture
Mounting Kit: KLV-2210



LVT-2300A

F-150 2004-2008 F-250 Light Duty 2004-2008 Mounting Kit: KLV-2310-Ford











LVT-2300

F-150*
F-250 Light Duty**
Ford Heritage
Ford Expedition
Lincoln Blackwood
Lincoln Navigator
*Fits Design for Plastic OEM Mirror
**Check Mirror to Match OEM Plcture
Mounting Kit: KLV-2310





LVT-2000

F-150* 1983-1998 F-250* 1983-1998 F-350* 1983-1998 Ford Ranger* 1983-1998 1983-1998 Ford Bronco* Ford Bronco II 1984-1990 Ford Club Wagon (Van) 1983-1991 Ford Econoline (Van) 1983-1991 *Fits Design for Chrome OEM Mirror Mounting Kit: KLV-2010





www.LongviewTM.com 33105 Kelly Road Fraser, MI 48026 248-844-1400

LVTFIT2019



LONGVIEW

LVT-1820

GMC Sierra* 2019-Current
Chevrolet Silverado* 2019-Current
* Fits New Body Style from Mid-2019
and with or with out under mirror
camera or puddle lights
Mounting Kit: KLV-1820









LVT-1600

GMC Sierra 2007-2013 Chevrolet Silverado/CK 2007-2013 GMC Yukon/Yukon XL 2007-2014 Chevrolet Suburban 2007-2014 Chevrolet Tahoe 2007-2014 Cadillac Escalade 2007-2014 2007-2013 Chevrolet Avalanche* *Will Not Fit Telescopic OEM Mirror Mounting Kit: KLV-4010



LVT-1400

Chevrolet Venture 1997-2005
Olsmovile Silhouette 1997-2005
Pontiac Montana 1997-2005
Pontiac Transport 1997-1999
Mounting Kit: KLV1410





LVT-1300

GMC Jimmy 1995-1998 Chevrolet Blazer/S10 1995-1998 GMC S-15 Pick Up 1994-1998 Chevrolet S-10 Pick Up 1995-1998 GMC Sonoma 1996-1998 GMC Envoy 1995-1998 Oldsmobile Bravada 1995-2000 1996-1997 Isuzu Hombre Mounting Kit: KLV-1310





LVT-1700

GMC Savana Van 1500 2002-2015 GMC Savana Van 2500 2003-2015 GMC Savana Van 3500 2006-2015 Chevrolet Express Van 1500 2003-2015 Chevrolet Express Van 2500 2003-2015 Chevrolet Express Van 3500 2006-2015 Mounting Kit: KLV-1710





LVT-1000

GMC Vandura (Van) 1978-1996 GMC Rally Wagon* 1978-1995 1978-1995 Chevrolet Van G 1978-1995 GMC Pick Up Chevrolet Pick Up 1978-1995 **GMC Sierra** 1984-1994 Chevrolet Silverado/CK 1984-1994 GMC Yukon XL 1978-1991 1978-1991 Chevrolet Suburban 1982-1989 Chevrolet Blazer Mounting Kit: KLV-1010





LVT-1100

GMC Jimmy 1982-1994 Oldsmobile Bravada 1982-1994 Chevrolet S-10 Pick Up 1982-1994 Chevrolet Blazer 1982-1994 GMC S-15 Pick Up 1982-1993 Chevrolet Astro Van 1985-1988

Mounting Kit: KLV-1110

LVT-1800

GMC Sierra* 2014-2019
Chevrolet Silverado* 2014-2019
GMC Sierra 2500** 2015-2019
Chevrolet Silverado 2500** 2015-2019
*Fits 2019 Old Body Style without puddle lights and camera
Mounting Kit: KLV-1810







LVT-1500

GMC Sierra 2000-2006 Chevrolet Silverado/CK 2000-2006 GMC Yukon/Yukon XL** 2000-2006 GMC Suburban** 2000-2006 2000-2006 Chevrolet Tahoe Chevrolet Suburban 2000-2006 2000-2006 Chevrolet Avalanche Cadillac Escalade* 2000-2006 *Will not fit Telescoping OEM Mirror **Will not fit Full Chrome OEM Mirror Mounting Kit: KLV-1510



LVT-1200

GMC Safari 1988-2005 Chefrolet Astro 1989-2004 **GMC** Sierra 1995-1999 Chevrolet Pick Up 1996-1999 1995-1998 Chevrolet Silverado/CK 1992-1999 GMC Yukon/Yukon XL Chevrolet Surburban 1992-1999 1992-1999 GMC Kodiak 1992-1999 Chevrolet Tahoe 1992-1999 Cadillac Escalade 1990-1994 Chevrolet Blazer



