



-INSTALLATION- INSTRUCTIONS

▶ LP AVENTURE HOOD LIGHT BRACKET ◀

SUBARU XV CROSSTREK 2013-2017

CONGRATULATIONS FOR YOUR NEW
LP AVENVENTURE HOOD LIGHT BRACKETS!



IN
THE
BOX





NECESSARY TOOLS

- Ratchet
- 12mm Socket



1

REMOVE TWO LOWER HOOD HINGE BOLTS





2

PLACE HOOD LIGHT BRACKET OVER HINGE BOLTS



3

RE INSTALL FACTORY NUT



4

REPEAT STEPS ON OTHER SIDE



INSTALLATION COMPLETE!



SPECIAL TIP: WHEN INSTALLING YOUR FOG LIGHTS ONTO YOUR NEW HOOD LIGHT BRACKETS. USE THE PROVIDED HOLES TO HELP SECURE THE CABLE

