



-INSTALLATION- INSTRUCTIONS

▶ LP AVENTURE REAR DIFFERENTIAL ◀
SKID PLATE

CONGRATULATIONS FOR YOUR NEW LP AVENTURE REAR DIFFERENTIAL SKID PLATE!

If you have any questions or need assistance during the installation please contact our team. You can find the information on the last page.



IN
THE
BOX





NECESSARY TOOLS

- We recommend the use of a lift
- Ratchet
- 17mm Socket
- 17mm Wrench
- Pry Bar

1

LOOSEN BUT DONT REMOVE TOP SUBFRAME NUTS.
ALLOW 1/4" OF MOVEMENT





2

REMOVE LOWER SUPPORT NUTS BUT LEAVE BOLTS IN





3

WITH THE HELP OF A PRY BAR SLIDE THE DIFF SKID IN BETWEEN THE DIFF AND THE SUBFRAME



4

TIGHTEN ALL HARDWARE



INSTALLATION COMPLETE!





NOTES:

****Tighten all the bolts to the manufacturer's specifications with a Torque Wrench****

**Double check your work.
and be sure to tighten
the nuts with a torque wrench.**
