Installation Instructions

LUNE

I - Sheet Number LUNDRB19 LUND Part#318093

Running Board Bracket Kit

For proper installation and best possible fit, please read all instructions BEFORE you begin.

Important Safety Information

• To be used with Lund® branded products only.

- Do not stand on Lund running board or bracket while vehicle is in motion.
- Do not use the brackets as a jacking point for the vehicle.
- Do not use the bracket system or running boards to fasten cargo.
- Periodically check all components for tightness.
- Be sure to wear safety glasses while installing brackets.
- When using power tools, read and understand all operating instructions.

Contents **NOTE:** Actual product may vary from illustration. 5/16 Square 5/16" Flange 8mm x 30mm 8mm Flat Front Brackets 8mm Lock Center and Rear Brackets Head Bolts (4) Nut (12) Hex Bolts (12) Washers (12) Washers (12) (2)(4)**Tools Required** Ratchet and Extension Socket Set Wheel Chocks Safety Glasses **Preparation Before Installation** • Park your vehicle in a clean, level location. Check to make sure the vehicle is in park, or for manual drive models, place the transmission in first gear. Engage the parking brake. Chock wheels. • Unpack the kit and identify the parts according to the content descriptions. • An assistant is recommended to help position the running board properly during the installation.

Installation Steps NOTE: Actual application may vary slightly from illustrations.

Starting on the passenger side of the vehicle, remove the existing (2) factory bolts located by the front tire opening securing the factory rocker panel bracket to the vehicle, (Figure 1).



1





Lund puts everything within reach.