



INSTALLATION INSTRUCTIONS



2015 BMW M3/M4 3.0L SPORT Black | PART NO. 19187

BILL OF MATERIALS:



1. **X-PIPE ASSEMBLY**
2. **D/S MID PIPE ASSEMBLY**
3. **P/S MID PIPE ASSEMBLY**
4. **MUFFLER ASSEMBLY.**



WEAR SAFETY
GLASSES



READ INSTRUCTIONS
THOROUGHLY BEFORE
INSTALLING PRODUCT

SHOP SUPPLIES:



SPRAY LUBRICANT

To ease removal of existing exhaust components (especially on older vehicles) spray penetrating lubricant on all fasteners and hangers/insulators that will be loosened or removed and let soak before disassembly.

HARDWARE KIT:

1. [2] 2.50" Clamp
2. [4] 3.00" V-Band Clamp
3. [2] Valve Adapter

MINIMUM REQUIRED TOOLS:



15mm



Hanger Tool
(Or Pry Bar)



Sawzall or similar
cutting tool

X INSTALLATION INSTRUCTIONS




Step 1. To remove the OEM exhaust system you will first need to unplug the exhaust valve control motors located on the OEM muffler assembly.



Step 2. To remove the OEM exhaust system you will need to cut the two outlet pipes behind the weld of each catalytic converter. The Drivers side needs to be cut 10.25" rearward and the passengers side 8.63". Disengage all welded hangers from the OEM rubber insulators. Do not discard the OEM fasteners or damage the rubber insulators as they will be needed to mount your new MAGNAFLOW system. Once the system has been removed you can unbolt the two exhaust control valves located on the muffler assembly.





Step 3. Install the new system by loosely securing the inlet pipes of the X-Pipe Assembly to the outlet pipes you have just cut using the supplied 2.50" clamps. Leave all clamps and fasteners loose for final adjustment of the complete system once installed.



Step 4. Loosely Install the D/S and P/S Mid Pipe Assemblies with the supplied V-Band Clamps.
****NOTE: Take care when using the V-Band Clamps, they are designed for one time use only. Once the clamp is tightened it can not be reused.**



Step 5. Install the Muffler Assembly using the same procedure for the V-Band Clamp. Engage the hanger bracket using the OEM hardware.



Step 6. Before fitting the valve motor to the valve assembly you will need to install the supplied adapter between the valve shaft and the motor as shown. The pins in the adapter are different sizes and can only go on one way. Make sure the larger pin locates to the valve assembly. You can now install the motor to the valve.



Step 7. Once a final position has been chosen for the new exhaust system, evenly tighten all clamps from front to rear using the torque specifications on page one of the instructions. Inspect all fasteners after 25-50 miles of operation and re-tighten if necessary.