




INSTALLATION INSTRUCTIONS



2003-2007.5 DODGE 2500/3500 5.9L | PART NO. 17876

BILL OF MATERIALS:



- 1. INLET ADAPTER. HO
- 2. INLET ADAPTER.
- 3. 25" EXTENSION PIPE
- 4. MUFFLER ASSEMBLY
- 5. OVER AXLE PIPE
- 6. TAIL PIPE



WEAR SAFETY GLASSES



READ INSTRUCTIONS THOROUGHLY BEFORE INSTALLING PRODUCT

SHOP SUPPLIES:



SPRAY LUBRICANT

To ease removal of existing exhaust components (especially on older vehicles) spray penetrating lubricant on all fasteners and hangers/insulators that will be loosened or removed and let soak before disassembly.

HARDWARE KIT:

- 1. [1] 3.50" Clamp
- 2. [1] 4.00" Clamp
- 3. [4] 5.00" Clamp
- 4. [1] Hanger Clamp #5 - 5"
- 5. [1] Hanger Clamp #7 - 5"

MINIMUM REQUIRED TOOLS:



15mm



Hanger Tool (Or Pry Bar)



Cutting Device


MAGNAFLOW RECOMMENDS PROFESSIONAL INSTALLATION ON ALL THEIR PRODUCTS




WARNING: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

ATTENTION: Always install any supplied band or U-bolt clamps to the proper torque specifications of 40-45 ft-lbs for band clamps and 30-35 ft-lbs for U-bolt clamps. Over tightening will result in the clamp breaking and will NOT be warranted by MagnaFlow.

INSTALLATION INSTRUCTIONS



Step 1. Working front to rear loosen or remove all OEM band clamps and disengage all welded hangers from the rubber insulators. Be sure to retain all mounting hardware as it will be needed to install your new MAGNAFLOW system.



Step 2. Install the corresponding Adapter Pipe pertaining to your vehicle and loosely fasten it to the catalytic converter outlet using the supplied clamp. Next, refer to the table below to select the appropriate extension pipes for your vehicles configuration. If applicable loosely attach the Extension Pipe to the Adapter Pipe using the supplied clamp.

| TABLE | |
|---------|----------|
| CAB/BED | 25" EXTN |
| SC/LB | NO |
| QC/SB | NO |
| QC/LB | YES |
| MC/SB | YES |



Step 3. Loosely attach the Muffler Assembly using the supplied clamps.



Step 4. Next, loosely slip the Hanger Clamp Assembly over the Over Axle Pipe. Loosely secure using the supplied clamps. Engage the welded hangers of the Hanger Clamp Assembly to the rubber insulators.



Step 5. Install the Tail Pipe Assembly in the same way. The Outlet may be trimmed as desired.



Step 6. Once a final position has been chosen for the new exhaust system, evenly tighten all clamps from front to rear using the torque specifications on page one of the instructions. Inspect all fasteners after 25-50 miles of operation and re-tighten if necessary.