




Kits# 22070 22080 22085

Chevy Small Block Double Serpentine Kit Long Water Pump

NOTE: Bracket shown in instructions are of our Deluxe Style Kit. Installation is the same for your Ultra Style Brackets

NOTE: Power Steering unit is a 1971 Impala style Keyway pump or 1977 Camaro V-8 Press-fit pump, you should have a 3/8" tap hole at the 6 O'clock both on the front and the rear of the unit. If you have a stud on the rear of the pump remove it.



BELTS FOR KITS

Dayco 5060425 for Alternator and Water Pump

Dayco 5060560 for A/C and Power Steering