



1. Install crank and alternator pulleys
2. Install alternator relocater brackets on top mount of alternator using one 3/8 x 1" socket head bolt.
3. Attach adjustment rod with assembled rod ends to relocater bracket using 3/8 x 1 1/4" bolt and locknut.
4. Install alternator bracket per drawing being sure to use the proper length spacers where noted in drawing. Meziere pumps will require the extra 3/8 x .100" washer between the backing plate and the 1.250" spacer.
5. Install the idler pulley to alternator bracket per drawing. Attach idler pulley cover.
6. Install and adjust belt (not included)

Belts

Kit# 30065 - 5.0 302 use Dayco #5060380 (38")
 Kit# 30060 - 351 Windsor use Dayco #5060400 (40")
 Kit# 30061 and 30066 will require measuring to determine correct belt size