



INSTALLATION INSTRUCTION

- Ensure all packing material and any loose magnet shavings are removed before Jeep Armor magnetic panel installation.
- Ensure the application and magnetic surface is clean and dry before reapplication.
- Temperatures outside of the specified range of -40 to 160 deg F could affect the magnetic panel's strength. Installation in temperatures outside of this range is not recommended.
- Remove panels from packaging and lay out allowing panels to fully flatten before application. If any Armor magnetic panel is shifted, misaligned or moved during use or installation, remove the entire panel and reposition to prevent scratching your vehicle's surface.
- Please note, Jeep limited edition models may have badges in different locations, the Trail Rated badge must be repositioned to fit the designed magnet panel cutout, any additional badges must be removed, repositioned or the Jeep Armor panel modified to fit around them ensuring a flush panel fit to the Jeep body without any lifted sections.

On our website you can discover more about armor & protection.