

INSTRUCTIONS

1. Plug the antenna adapter in the vehicle.
2. Locate which antenna coaxial is present on the factory side and use that coaxial input.
3. Connect the **Blue** wire to the power antenna wire of the aftermarket radio.