



70-1785

INSTALLATION INSTRUCTIONS

Amplified / Bose

Integration Harness

1988-95 Audi/Volkswagon

NOTE:

For **Audi** vehicles, be sure to insert the Blue/White wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, the Blue/White wire also supplies the signal to turn on the antenna.

For **Volkswagen** vehicles, be sure to insert the Blue/White wire (supplied) into pin 3 on the 16-way harness, right next to the Red accessory wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, insert the Blue wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's antenna turn-on wire.



For amplified models:

- 1988-89 Volkswagen Golf
- 1988-89 Volkswagen GTI
- 1988-89 Volkswagen Jetta

Connect the White, White/Black, Gray, and Gray/Black speaker wires to the front speaker outputs of the aftermarket radio, and the Green, Green/Black, Purple, and Purple/Black speaker wires to the radio's rear speaker outputs. Connect the White and Gray RCA's to the radio's front RCA outputs to run the speakers in the front doors. The Green and Purple RCA's will not be used.

For amplified models:

- 1994-95 Audi Cabriolet
- 1994 Audi S4
- 1988-92 Audi 80
- 1988-95 Audi 90
- 1992-94 Audi 100 w/o Bose
- 1989-91 Audi 200

Connect the White, White/Black, Gray, and Gray/Black speaker wires to the radio's front speaker outputs. Connect the Green and Purple RCA's to the radio's rear RCA outputs for the rear speakers. The Green, Green/Black, Purple, and Purple/Black speaker wires along with the White and Gray RCA's are not used.

For amplified models:

- 1995 Audi A6
- 1995 Audi S6
- 1990-93 Audi V8 Quattro
- 1992-94 Audi 100 w/Bose
- 1991-93 Volkswagen Cabriolet
- 1990-93 Volkswagen Corrado
- 1990-92 Volkswagen Golf
- 1990-92 Volkswagen GTI
- 1990-92 Volkswagen Jetta
- 1990-92 Volkswagen Passat

Connect the White and Gray RCA's to the radio's front RCA outputs for the front speakers and the Green and Purple RCA's to the radio's rear RCA outputs for the rear speakers. The speaker wires on the 16-way harness will not be used at all.