



Installation Instructions for 70-1787

70-1787 Audi/Porsche/VW Bose integration harness 1993-2007

APPLICATIONS

AUDI		PORSCHE	
A3	2006-2007	Boxster	1997-2004
A4	1996-2006		
A6	1998-2004	VOLKSWAGEN	
A6 Quattro	1998-1999	Beetle	1998
A8	1997-2003	Golf	1993-1997
allroad	2001-2005	Jetta	1993-1997
TT	2000-2006		

Caution: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

***Note:** Refer also to the instructions included with the aftermarket radio.

Connections to be made

From the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire the battery wire.
- Connect the **Red** wire the accessory wire.

Note: If a wire is not populated on the factory side, an accessory wire will need to be run to the fuse box.

- Connect the **Orange/White** wire to the illumination wire. If the aftermarket radio has no illumination wire, tape off and disregard the **Orange/White** wire.

Note: If a wire is not populated on the factory side, an illumination wire will need to be run to the lighting circuit of the vehicle.

Installation Instructions for 70-1787

- Connect the **Blue/White** wire to the amp turn on wire. This wire must be connected to hear sound from the factory amplifier.
- For models with a power antenna, insert the **Blue** wire into the cavity above the **Yellow** wire, and then connect this wire to the antenna turn on wire.

Note: 1998 and up vehicles will not require this to be done as the antenna turn wire will be in the antenna itself. Use Metra part number 40-VW54 for these applications.

For models without Bose:

- Connect the **White** wire to the left front positive speaker output.
- Connect the **White/Black** wire to the left front negative speaker output.
- Connect the **Gray** wire to the right front positive speaker output.
- Connect the **Gray/Black** wire to the right front negative speaker output.
- Cap off and disregard the **Purple, Purple/Black, Green, and Green/Black** wires.
- Connect the **Green** RCA jack to the left rear RCA jack output.
- Connect the **Purple** RCA jack to the right rear RCA jack output.
- Disregard the **White** and **Gray** RCA jacks.

For models with Bose:

- Cap off and disregard the **White, White/Black, Gray, Gray/Black, Purple, Purple/Black, Green, and Green/Black** wires.
- Connect the **White** RCA jack to the left front RCA jack output.
- Connect the **Gray** RCA jack to the right front RCA jack output.
- Connect the **Green** RCA jack to the left rear RCA jack output.
- Connect the **Purple** RCA jack to the right rear RCA jack output.