



70-2003 / 80-2003

Due to the fact that a switched 12-volt accessory lead does NOT exist in the factory harness, an accessory source must be located. Do NOT use the 2003's 12-volt accessory wire for these vehicles. On vehicles with (*) the separate red wire is NOT needed.

1. Using the separate red wire provided with the fuse tap, locate an accessory power source in the vehicle's fuse box.
2. Connect this red wire to the aftermarket head unit switched accessory lead.
3. Use Metra's standard wiring instructions for the remainder of the installation.

NOTES:

1. To retain factory chimes and the Retained Accessory Power feature use Axxess GMRC-02.
2. For vehicles equipped with Onstar that are NOT factory amplified use Axxess GMOS-01.
3. For vehicles equipped with a factory amplified system, with or without Onstar, use Axxess GMOS-04.

NOT FOR USE WITH BOSE OR MONSOON AMPLIFIED SYSTEMS EXCEPT HYUNDAI SANTA FE, KIA SORRENTO AND PONTIAC VIBE.



70-2003 / 80-2003

INSTALLATION INSTRUCTIONS

1998-Up Wiring Harness

BUICK

CENTURY 2004-05
LACROSSE 2005-09
RAINIER 2004-07
RENDEZVOUS 2002-07
TERRAZA 2005-08

CHEVROLET

AVALANCHE (NON BOSE) 2003-06
*BLAZER 2002-05
CAVALIER 2000-05
CLASSIC 2004-05
COLORADO 2004-10
CORVETTE 2005-10
EXPRESS 2003-07
*EXPRESS VAN 2001-02
IMPALA 2000-05
KODIAK (C4500&C8500) 2005-09
MALIBU 2001-03
MONTE CARLO 2000-05
SILVERADO 2003-06
SILVERADO (CLASSIC) 2007
SSR 2003-06
SUBURBAN (NON-BOSE) 2003-06
*S-10 PICKUP 2002-04
TAHOE (NON-BOSE) 2003-06
TOPKICK (C4500&C8500) 2005-09
TRAILBLAZER (NON-BOSE) 2002-09
UPLANDER 2005-08
VENTURE VAN 2000-05

GEO

*METRO 2000-01
*PRISM 2000-03
*TRACKER 1998-04

GMC

CANYON 2004-10

ENVOY (NON-BOSE) 2002-09
SAVANA VAN 2003-07
*SAVANA VAN 2001-02
SIERRA 2003-06
SIERRA (CLASSIC) 2007
SONOMA 2002-04
YUKON (ALL NON-BOSE) 2003-06

HUMMER

H3 2006-10

HYUNDAI

*SANTA FE (W/ MONSOON) 2003-06

ISUZU

ASCENDER 2003-08
I SERIES 2006-08

KIA

*SORENTO EX 2003-06
*LX SPORT (DOUBLE DIN)

PONTIAC

AZTEC 2001-05
GRAND AM 2001-05
GRANDPRIX 2004-08
*MATRIX 2003-04
MONTANA MINI VAN 2000-06
SUNFIRE 2000-05
*VIBE 2003-08

OLDSMOBILE

ALERO 2001-04
BRAVADA 2002-04
INTRIGUE 2002
SILHOUETTE 2000-04
SATURN RELAY 2005-07

SUZUKI

*VITARA 1999-04